


# 録画再生の操作手順

この手順書では、Uniview製ネットワークレコーダで録画映像を再生する操作手順を説明します

# 1.再生画面の表示



または画面上で右クリックを行い、コンテキストメニューから「再生」をクリックする



## 2.再生するカメラの選択

画面右側のカメラ一覧から、再生するカメラにチェックを入れる

The screenshot displays a video player interface. At the top, there are tabs for 'ノーマル' (Normal) and '高解像度' (High Resolution). On the right side, a camera selection menu is open, showing a list of 16 IP cameras. The first camera, 'IP Camera 01', is selected, indicated by a blue highlight and a checked checkbox. A yellow callout box with a pointer highlights the checkboxes for each camera. Below the camera list, there is a calendar for November 2018, with the 13th highlighted. At the bottom, there is a playback timeline with a progress bar and various control buttons like play, stop, and volume.

選択	カメラ名
<input checked="" type="checkbox"/>	IP Camera 01
<input type="checkbox"/>	IP Camera 02
<input type="checkbox"/>	IP Camera 03
<input type="checkbox"/>	IP Camera 04
<input type="checkbox"/>	IP Camera 05
<input type="checkbox"/>	IP Camera 06
<input type="checkbox"/>	IP Camera 07
<input type="checkbox"/>	IP Camera 08
<input type="checkbox"/>	IP Camera 09
<input type="checkbox"/>	IP Camera 10
<input type="checkbox"/>	IP Camera 11
<input type="checkbox"/>	IP Camera 12
<input type="checkbox"/>	IP Camera 13
<input type="checkbox"/>	IP Camera 14
<input type="checkbox"/>	IP Camera 15
<input type="checkbox"/>	IP Camera 16

11月 2018

日	月	火	水	木	金	土
				1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	

00:00:00

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24

ノーマル イベント

### 3.再生する年月日の選択

The screenshot shows a video player interface. At the top, there are tabs for 'ノーマル' (Normal) and '高解像度' (High Resolution). On the right, a list of cameras is shown, with 'IP Camera 01' selected. Below the camera list is a calendar for November 2018. A yellow callout box explains that the calendar is used to select the date for playback, with blue indicating normal recording and red indicating event recording. The bottom of the screen shows a timeline with a play button and a legend for 'ノーマル' (blue) and 'イベント' (red).

カメラ一覧の下に表示されるカレンダーから再生する年月日を設定する

※ 日付のバックカラーが青の日付：■ はノーマル録画、赤の日付：■ はイベント録画のデータが存在することを表す

日	月	火	水	木	金	土
				1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	

## 4-1.再生する時間の選択

The screenshot shows a video player interface. At the top, there are dropdown menus for 'ノーマル' (Normal) and '高解像度' (High Resolution). On the right, there is a list of cameras from 'IP Camera 01' to 'IP Camera 16'. 'IP Camera 01' is selected. Below the camera list is a calendar for November 2018. The date '13' is highlighted. At the bottom, there is a timeline with a red box around it, showing a time range from 09:12:52 to 09:13:52. The timeline has a blue bar for 'ノーマル' (Normal) and a red bar for 'イベント' (Event). Below the timeline are playback controls including play, stop, previous, next, and volume buttons.

画面下のタイムラインから再生時間を選択する  
※ 録画データの有無はタイムライン上に色で表示される  
青：ノーマル録画、赤：イベント録画

録画データの表示は上下2段に分かれており  
上段：現在表示している特定の1chの録画状態  
下段：再生対象として選択された全chの録画状態を表す

## 4-2.タイムラインのズームイン・アウト

The screenshot shows a video editing software interface. At the top, there are dropdown menus for 'ノーマル' (Normal) and '高解像度' (High Resolution). The main area is a dark timeline. On the right side, there is a list of cameras from 'IP Camera 01' to 'IP Camera 15'. Below this list, there are zoom controls. A yellow callout box points to these controls, containing the text: 'タイムラインの表示間隔はタイムライン右側の「ズームイン」・「ズームアウト」アイコンで調整する' and '※ ズームイン：↔、ズームアウト：→←'. The zoom controls consist of two icons: a double-headed arrow (↔) for zoom in and a right arrow followed by a left arrow (→←) for zoom out. These icons are highlighted with a red box. The timeline itself has a scale from 0 to 6, with a playhead at 00:00:00. At the bottom, there are various playback controls and a volume slider.

タイムラインの表示間隔はタイムライン右側の「ズームイン」・「ズームアウト」アイコンで調整する  
※ ズームイン：↔、ズームアウト：→←

# 5.録画データの再生

7

The screenshot shows a video player interface with a dark theme. At the top, there are dropdown menus for 'ノーマル' (Normal) and '高解像度' (High Resolution). The main area is a large black rectangle. On the right side, there is a list of cameras with checkboxes. 'IP Camera 01' is selected. Below the list is a calendar for November 2018. At the bottom, there is a timeline with a red play button icon highlighted by a red box. A yellow callout box points to the play button with the text: 録画データ検索条件を設定後、画面下の「再生」アイコンをクリックする (After setting the recording data search conditions, click the 'Play' icon at the bottom of the screen).

ノーマル 高解像度

すべて すべて閉じる

選択	カメラ名
<input checked="" type="checkbox"/>	IP Camera 01
<input type="checkbox"/>	IP Camera 02
<input type="checkbox"/>	IP Camera 03
<input type="checkbox"/>	IP Camera 04
<input type="checkbox"/>	IP Camera 05
<input type="checkbox"/>	IP Camera 06
<input type="checkbox"/>	IP Camera 07
<input type="checkbox"/>	IP Camera 08
<input type="checkbox"/>	IP Camera 09
<input type="checkbox"/>	IP Camera 10
<input type="checkbox"/>	IP Camera 11
<input type="checkbox"/>	IP Camera 12
<input type="checkbox"/>	IP Camera 13
<input type="checkbox"/>	IP Camera 14
<input type="checkbox"/>	IP Camera 15
<input type="checkbox"/>	IP Camera 16

11月 2018

日	月	火	水	木	金	土
				1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	

録画データ検索条件を設定後、画面下の「再生」アイコンをクリックする

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24

ノーマル イベント



# 6-1.再生画面での操作1

再生開始後はコントロールボタンのアイコンをクリックすることで再生画面の速度変更などの操作が可能

再生/一時停止

停止

逆再生

30秒前に戻る

30秒後に進む

巻き戻し (×1~×256)

早送り (×1~×256)

コマ送り

2018-11-13 09:12:56

カメラ名

選択	カメラ名
<input checked="" type="checkbox"/>	IP Camera 01
<input type="checkbox"/>	IP Camera 02
<input type="checkbox"/>	IP Camera 03
<input type="checkbox"/>	IP Camera 04
<input type="checkbox"/>	IP Camera 05
<input type="checkbox"/>	IP Camera 06
<input type="checkbox"/>	IP Camera 07
<input type="checkbox"/>	IP Camera 08
<input type="checkbox"/>	IP Camera 09
<input type="checkbox"/>	IP Camera 10
<input type="checkbox"/>	IP Camera 11
<input type="checkbox"/>	IP Camera 12
<input type="checkbox"/>	IP Camera 13
<input type="checkbox"/>	IP Camera 14
<input type="checkbox"/>	IP Camera 15
<input type="checkbox"/>	IP Camera 16

11月 2018

日	月	火	水	木	金	土
				1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	

09:12:55

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24












1x

ノーマル イベント



## 6-2.再生画面での操作2

再生時に画面左下のコントロールボタンのアイコンをクリックすることで再生画面での操作が可能


















-  /  : クリップ開始/終了
-  : スナップショット
-  : 録画データの保護
-  : デフォルトタグを追加
-  : カスタムタグを追加
-  : ファイル管理画面の表示
-  : デジタルズーム
-  /  : イベント録画の表示、非表示切り替え
-  : 魚眼モードの表示

画面右側のカメラリスト:

選択	カメラ名
<input checked="" type="checkbox"/>	IP Camera 01
<input type="checkbox"/>	IP Camera 02
<input type="checkbox"/>	IP Camera 03
<input type="checkbox"/>	IP Camera 04
<input type="checkbox"/>	IP Camera 05
<input type="checkbox"/>	IP Camera 06
<input type="checkbox"/>	IP Camera 07
<input type="checkbox"/>	IP Camera 08
<input type="checkbox"/>	IP Camera 09
<input type="checkbox"/>	IP Camera 10
<input type="checkbox"/>	IP Camera 11
<input type="checkbox"/>	IP Camera 12
<input type="checkbox"/>	IP Camera 13
<input type="checkbox"/>	IP Camera 14
<input type="checkbox"/>	IP Camera 15
<input type="checkbox"/>	IP Camera 16

画面下部のタイムラインとコントロール:

タイムライン: 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24

コントロールボタン:                  1x

画面右下の表示: ノーマル イベント

# 7-1. 「フルスクリーン」画面への切り替え



画面右上の「フルスクリーン」アイコンをクリックする

2018-11-13 09:12:56

画面右下のカメラリスト:

- IP Camera 01
- IP Camera 02
- IP Camera 03
- IP Camera 04
- IP Camera 05
- IP Camera 06
- IP Camera 07
- IP Camera 08
- IP Camera 09
- IP Camera 10
- IP Camera 11
- IP Camera 12
- IP Camera 13
- IP Camera 14
- IP Camera 15
- IP Camera 16

画面下部のタイムラインと操作ボタン:

09:12:55


0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24

操作ボタン: 拡大縮小、カメラ切替、ロック、設定、録画、再生、停止、全画面表示、1x

画面右下の表示モード: ノーマル イベント

## 7-2.「フルスクリーン」表示画面

2018-11-13 00:00:28



※ フルスクリーンの状態では再生速度の変更、録画の停止などの操作を行うことができません  
フルスクリーン画面から通常の再生画面に戻るにはマウスの右クリックで戻ることが可能です



## 8. ライブ画面への戻り方



画面右上の「終了」アイコンをクリックする  
または、画面上でマウスの右クリックを行うことでライブ画面に戻る

2018-11-13 09:12:56

カメラリスト:

- Camera 01
- Camera 02
- Camera 03
- IP Camera 04
- IP Camera 05
- IP Camera 06
- IP Camera 07
- IP Camera 08
- IP Camera 09
- IP Camera 10
- IP Camera 11
- IP Camera 12
- IP Camera 13
- IP Camera 14
- IP Camera 15
- IP Camera 16

カレンダー: 2018年11月

日	月	火	水	木	金	土
				1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	

タイムライン: 09:12:55

操作ボタン: 終了, 設定, 拡大, 縮小, 録画, 再生, 停止, 一時停止, 戻る, 進む, 1x

レコーダー状態: ノーマル (青), イベント (赤)